



Care & Maintenance Instructions

To maintain your warranty and to extend the life of your products, the following inspection, maintenance & care conditions must be carried out.

INSPECTION CONDITIONS

Every 3 months you must check for:

Lichen, moss, leaves, pollen and salt residue.

Minor white oxidisation especially on fascia & spouting bends or crevices.

Fasteners showing signs of corrosion.

Action Wash

Wash

Contact Vendor

MINIMUM MAINTENANCE REQUIREMENTS

In addition to the above, you must always complete the following:

- Wash the painted surface of all products at least every 6 months.
- Removal of debris from the inside of your spouting at least every 6 months.

HOW TO CARE FOR YOUR PRODUCTS

General wash Painted surface	To remove any objectionable surface dirt, salts and stains, use a low-pressure spray (less than 1000psi) &/or use water and a soft nylon bristled brush. We also recommend the use of ColorCote Roof Wash for your regular 6 monthly ongoing maintenance.
Removing lichen, mould or pollen	Apply ColorCote Roof Wash in accordance with label instructions. Apply from ground level. Do not rinse off. ColorCote Roof Wash is a long-acting product so immediate results may not be noticeable. If Lichen and Mould remain after 2-3 months, repeat the process.
Removing white oxidisation	White deposits sometimes become obvious on Spouting & Fascia, particularly on the bends. This is a natural reaction of the metal and should not cause concern, however it is visually apparent and can be easily cleaned off if attended to early. Use water and a soft nylon bristle brush, as per general wash above.
Cleaning the inside of spouting	When cleaning the inside of the spouting, please take care of where sealant is placed as scraping or water blasting the sealant may cause it to un-adhere. This will cause your spouting to leak and is not covered by your warranty.
Painting	When considering over painting please consult with your local Vendor to ensure correct procedures are undertaken. Use of the incorrect paint &/or procedure will void your warranty.
Copper	If you have selected our copper finish, then this product requires no maintenance

The finish on these products, like any other coloured or painted surface, is susceptible to colour change due to normal weathering, wear and tear.

Under normal conditions periodic cleaning with a garden hose and soft nylon bristled brush will remove and help deter the accumulation of objectionable surface dirt, salts and stains.

For more information or to purchase cleaning products, please refer to the following websites: https://continuous.co.nz/nz-spouting-services/care-maintenance https://www.colorcote.co.nz/technical-assets/